

# Repair Procedures


- Damaging of test parts using a drop weight tester

Drop weight  
tester from  
Zwick/Roell AG  
(left)  
Manual impact  
test (right)




# Repair Procedures

- Damaged test parts (GRP/CRP)




Damaged GRP parts



Damaged CRP parts

# Repair Procedures

- Type 1 repairing procedure: dry inserts




# Repair Procedures

- Manufacturing and treating of parts for repair



Positive parts






Milling of damaged parts



# Repair Procedures

- Milled parts



Milled CRP part

Milled GRP parts


# Repair Procedures

- Grouting of parts



# Repair Procedures


- Result of type 1 repair procedure



Milled GRP and CRP parts

# Repair Procedures



- Type 2 repairing procedure: wet laminating





# Repair Procedures

- Grinding of damaged area



Milled GRP parts

# Repair Procedures

- Adding new fibre mats



CRP part repair

# Repair Procedures

- Grouting of new and old fibres




GRP and CRP test parts



# Repair Procedures

- Post processing of repaired test parts




Milling of GRP test part



Grinding of GRP test part

# Repair Procedures

- Result of type 2 procedure




Repaired GRP and CRP test part



# Repair Procedures


- Pre-processing test parts for Compression tests



Soldering of strain gauges

# Repair Procedures


- Pre-processing test parts for Compression tests



Test parts with strain gauges – ready for compression tests

# Repair Procedures

- Compression after impact tests



Connecting strain gauges with measurement equipment



# Repair Procedures


- Compression after impact (CAI) tests



Universal testing machine (left) and specimen holder tool (right)

# Repair Procedures

- Result of CAI tests in software testXpert



Strain gauges  
adapted at  
testpart (left)  
Stress-strain  
diagram (right)